



UET Mixers Inc.  
26 Maple St.  
Mechanic Falls, ME 04256  
Tel: (207)-345-3330  
Toll Free: (888)-838-9131  
Fax: (603)-627-9328

## XCEL Series of Turbine Mixers

Bulletin 03-110  
12/20/11  
Supersedes 6/5/98

Page  
01 of 01

### Flush Port Operation

#### 1. Connection Procedure

- A. Connect your water flush line to the mixer flush port (normally 1/4" NPT) located on the perimeter of the seal mounting flange. The flush Port Directs the water to the interior of the flange which houses the throttle bushing.

**NOTE:** Water must be pumped to the bushing continuously to protect the mechanical seal from the contents of the tank.

